

Seed purity selection using NIR hyperspectral imaging



Dr. Fred Hugen

Business development SeQso



SeQso, Fred Hugen
EPIC Online Technology Meeting on
Hyperspectral Imaging

Contents

- Background
- Problem definition / why hyperspectral imaging
- Solution
- Lessons learned



Background SeQso

- Company in development and manufacturing of advanced machines and instruments for seed industry involving:
 - Analysis
 - Sorting
 - Precision sowing
- Multi modal imaging
 - RGB
 - Fluorescence
 - X-Ray
 - Hyperspectral (VIS – NIR – SWIR)







Purity sorting (phenotype)

- Select all seeds belonging to a certain crop
- The remainder is the “debris”
- Case:
 - Oats purity (ingredient in food for gluten free diet)
 - Toughest problem is detection of barley seeds
 - Typical “bad” residual = 10 .. 100ppm
 - Get a debris fraction less 1% of total seed lot with 98% of all bad residual



Sample images




Barley

Oats

Rye

Wheat



SeQso, Fred Hugen
EPIC Online Technology Meeting on
Hyperspectral Imaging




Solution

- Sorting machine with a belt with 22 parallel lanes
- Positive selection (blow off everything recognized as an oat)
- Using 12MP high-res RGB color imaging for shape, texture and color analysis
- Using a NIR spectrum for additional measurement data especially for detection of barley



System overview

Principe II



SeQso, Fred Hugen
EPIC Online Technology Meeting on
Hyperspectral Imaging

Why hyperspectral imaging?



- There are 22 lanes -> 22 channels for a spectrometer
- Problem for a spectrometer probe is the difference in position/orientation and height of seeds
- Mixing of belt / seed at border of the seed
- Internal part of the oat seed



Hyperspectral imager

- Specim FX17
 - 640 spatial pixels (0.3mm / pixel)
 - 224 bands (used 194)
 - Range 950nm .. 1700nm
- Halogen illumination
 - 10 bulbs of 50W, 12VDC stabilized

Classification



Oat upper side



Barley



Oat down side

Lessons learned

- NIR Hyperspectral imaging requires expensive equipment but is very versatile for biological objects
- Preprocessing of signals is required (normalization / calibration / bad pixels)
- Problems with temperature stability (halogen illumination 500W, camera cooling stability)



Take your next step with Hyperspectral imaging!

“Thanks for your attention”



SeQso, Fred Hugen
EPIC Online Technology Meeting on
Hyperspectral Imaging